

## Blade Replacement Instructions for AirCell® Power Tools

7

For use with PPT012-PIM

**Instructions should be read thoroughly prior to blade replacement.**

### Additional Tools Required

Hex Wrench, 3/32

Hex Wrench, 5/64

### Blade Replacement Kit PPT012-PIMRB

(1) CB6667H

(1) CB292

### Blade Replacement

#### Jacket Strip Blade CB6667H

Remove blade by loosening the socket head cap screw with a 3/32 hex wrench (Figure 1). Blade is slotted and should be positioned completely away from the center of the tool. Install new blade by tightening the socket head cap screw securely.

#### Outer Conductor Chamfer CB292

Remove blade by loosening the button head socket screw with a 5/64 hex wrench (Figure 2). Blade requires no adjustment. Install new blade by tightening the button head socket screw securely.



Figure 1




Figure 2

Notice: Trilogy disclaims any liability or responsibility for the results of improper or unsafe installation, inspection, maintenance, or removal practices.