

Blade Replacement Instructions for AirCell® Power Tools

6

For use with CT11450P and CT15850P

Instructions should be read thoroughly prior to blade replacement.

Additional Tools Required

Hex Wrench, 5/32

Blade Replacement Kit CT114/158RB/3PK

(3) CB214

Blade Replacement

Jacket Strip Blade CB214

Remove blade by loosening the socket head cap screw with a 5/32 hex wrench (Figure 1). Blade requires no adjustment. Install new blade by tightening the socket head cap screw securely.

Outer Conductor Chamfer CB214

Remove blade by loosening the socket head cap screw with a 5/32 hex wrench (Figure 2). Blade requires no adjustment. Install new blade by tightening the socket head cap screw securely.

Dielectric Blade CB214

Remove blade by loosening the socket head cap screw with a 5/32 hex wrench (Figure 3). Blade requires no adjustment. Install new blade by tightening the socket head cap screw securely.



Figure 1



Figure 2



Figure 3

Notice: Trilogy disclaims any liability or responsibility for the results of improper or unsafe installation, inspection, maintenance, or removal practices.